Licensing

flexAI systems use licenses to enable the flexAI engine as well as additional audio processing components, interfaces, and other optional features. Depending on the installation, licenses may be provided locally via a USB license dongle or centrally through a **Wibu license server**.


Select **Licensing** from the **System** menu to view the currently installed licenses.

The **Product Name** and **Product Code** identify each licensed product or feature. **Quantity** shows the total number of licenses available for that product, while **Available** shows how many of these licenses are currently not in use.

Some licenses, such as licenses provided for demonstrations or evaluations, are valid for a limited period. For these licenses, an **Expiration Time** is shown on the **Licensing** page. After this date, the corresponding licensed feature is no longer available unless the license is renewed or replaced.

When purchasing or activating additional licenses, you may be asked to provide a **License Request**. To create it, use **Download License Context File** in the lower-left corner of the **Licensing** page. The downloaded file contains the license context information required to generate the corresponding license update.

Once you receive the **License Update File**, use **Upload License Update File** in the lower-right corner of the page to install or update the licenses on the flexAI system.



Revision #1
Created 2026-09-04 10:58:18 UTC by FK
Updated 2026-09-04 10:58:32 UTC by FK