

Routing Presets

Presets can be managed by clicking on the Preset icons:



Parameter	Function
File Icon	Open the Load Preset dialog
Floppy Disc Icon	Open the Save Preset dialog
Three Dots Icon	Open more dialogs (Preset Operations), mainly used to open the Delete Preset dialog

Save Presets

Save Preset for Main Routing (Default)

Save Preset As

<New Preset>

Preset Name

Enter Preset name here

Preset Description

Enter a helpful description here (optional)

OK

CANCEL

Parameter - Save Preset	Function
Save Preset As	Select to create a new preset or overwrite an existing preset.
Preset Name	Enter a preset name here.
Preset Description	Optionally a description can be added to help identifying presets.

Load Presets

Load Preset for Main Routing (Default)

Load Preset

Preset 3

Preset Description

This is the third routing preset

Load Behavior

☐ Preserve Existing

☐ Replace Existing

☒ Remove Existing

OK

CANCEL

Parameter - Load Preset	Function
Load Preset	Select the preset to load.
Preset Description	The description helps identifying presets.
Load Behaviour	Decides what happens to existing routings.
Preserve Existing	Routings in the preset will be added to the existing routings. This might cause conflicts when destinations are used in multiple connections.

Parameter - Load Preset	Function
Replace Existing	Replaces routings with the same destinations only.
Remove Existing	Removes all existing routings and creates new routing connections from the preset values.

Preset Operations (Delete Presets)

Preset Operations for Main Routing (Default)

DELETE

☐

PRESET NAME

☐

Preset 1

☐

Preset 2

☐

Preset 3

DELETE SELECTED PRESETS

Parameter - Delete Preset	Function
Select Preset	Select the preset(s) to delete.
Bin Icon	Delete individual presets.
Delete Selected Presets	Delete all selected presets.